

Net2 Caller ID reader

System specifications


Phone support	Caller ID enabled
Carrier frequency	Quad band GSM
Additional PSU needed	No
SIM provided	UK only

Electrical

Operating Voltage	10V - 14V DC
Current consumption	500mA

Environment

Operating temperature	-20°C - +55°C -4°F - +131°F
Moisture resistance	No - if used externally, it must be protected in a weatherproof housing
Vandal Resistance	Low



The Net2 Caller ID reader enables phones to be used as Net2 tokens, without incurring any call charges, through caller ID (CLID) technology.

The Net2 Caller ID reader is installed between an existing Net2 reader (if there is one) and any Net2 control unit, the Net2 reader will function as normal.

The Net2 Caller ID reader is powered from the reader port and can be connected to either reader port 1 or 2. If you wish it can be installed as your only reader.


The Net2 Caller ID reader uses the last 8 digits of your phone number as the token number. It uses the caller ID feature so it is able to identify the caller without making a connection.

A mobile SIM is provided, but you may use your own if you wish. Visit the website www.paxton.info/1713 to register your SIM, once registered it will be online within one hour. This SIM guarantees that you won't be disconnected from the network and offers quad network support for maximum coverage.

Note: SIM is provided in the UK only

To add your phone as a token within the Net2 software, enter the last 8 digits of your phone number as the token number.

The Net2 Caller ID reader means that you no longer need tokens so it's great for remote clocking in, communal entrances, infrequently visited sites, switching power, letting the kids in and of course, car park barriers.



Accessories and sales codes

Net2 Caller ID reader

460-210